

TRIO T-WELL USC 6690 WB

ULTRASONIC CLEANER

USC 6690 WB; It is a water-based product specially developed for ultrasonic washing machines for cleaning oil, grease, dirt and carbon deposits.

PRODUCT FEATURES AND BENEFITS

1. It does not contain hydrocarbon and solvent components and is biologically degradable in nature.
2. It is not corrosive, it does not damage the parts to be cleaned and the ultrasonic cleaning machine. Also suitable for use on painted parts.
3. Foam is controlled and does not cause foam-induced problems during cleaning and heating.
4. It is an economical product, it is easy to use.

DOSAGE AMOUNT AND INTENDED USE

The ultrasonic bath must be degassed before use. The device should be operated for 3-5 minutes before the parts to be cleaned are placed in the bathroom. In devices with approximately 50 liters of water tank, 3-10 liters of USC6690WB should be added depending on the contamination situation. The temperature must be 60-80°C. Depending on the amount of deposits, cleaning time should be determined between 30 minutes and 5 hours. The same solution can be used several times until it loses its effectiveness.

NOTE: Please review the MSDS reports before use for safety, occupational health and safety.